

Level of Difficulty

Easy

Installation difficulty levels are based on time and effort involved and may vary depending on the installer level of expertise, condition of the vehicle and proper tools and equipment.

Product Photo



Parts List

Item	Qty	Description
1	1	Drop shank, 2"
2	1	Adapter plate
3	2	Support brace
4	8	Carriage bolt, 5/16"
5	8	Flat washer, 5/16"
6	8	Flange nut, 5/16"

Tools Required

Ratchet	Drill
Socket, 1/2"	Phillips head drill bit
Wrench, 1/2"	--

* For a tools reference guide visit
curtmfg.com/trailer-hitch-installation

NOTICE

Visit www.luvernetruck.com for a full-color copy of this instruction manual, as well as helpful videos, guides and much more!

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

Periodic inspection of your product should be performed to ensure all hardware and / or components remain secure.

Product Registration and Warranty

LUVERNE stands behind our products with industry-leading warranties. To get copies of the product warranties, register your purchase or provide feedback, visit: warranty.curtpgroup.com/surveys

Assembly

Attach the end caps to the Grip Step™ board, using the four self-drilling screws.

Using four carriage bolts (#4), flat washers (#5) and flange nuts (#6), attach the adapter plate (#2) to the 2" shank (#1).

Slide the support braces (#3) into the Grip Step™ board and attach to the adapter plate using four carriage bolts, washers and nuts.

NOTICE

Running board 415026 is sold separately.

