

# INSTALLATION MANUAL

# 13631

## Level of Difficulty

Moderate

Installation difficulty levels are based on time and effort involved and may vary depending on the installer level of expertise, condition of the vehicle and proper tools and equipment.

## Weight Carrying Capacity

Gross trailer weight (GTW)	3,500 lbs.
Tongue weight (TW)	350 lbs.

## Parts List

Item	Qty	Description
1	1	Trailer hitch
2	4	Hex bolt, M12 x 1.25 - 35mm
3	4	Conical-toothed washer, 1/2"

## Tools Required

Ratchet	Flathead screwdriver
Socket, 12mm	Paint marker
Socket, 19mm	Tape measure
Torque wrench	Cut-off wheel

\* For a tools reference guide visit [curtmfg.com/trailer-hitch-installation](http://curtmfg.com/trailer-hitch-installation)

## Product Registration and Warranty

CURT stands behind our products with industry-leading warranties. To get copies of the product warranties, register your purchase or provide feedback, visit: [warranty.curtgroup.com/surveys](http://warranty.curtgroup.com/surveys)

## ⚠ WARNING

Never exceed the vehicle manufacturer's recommended towing capacity.

## Product Photo



## NOTICE

Visit [www.curtmfg.com](http://www.curtmfg.com) for a full-color copy of this instruction manual, as well as helpful videos, guides and much more!

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

This installation requires:

- Temporary part removal and trimming of the underbody panel.

Periodic inspection of the trailer hitch should be performed to ensure all mounting hardware remains tight and structural components are secure.

To help prevent damage to the product or vehicle, refer to the specified torque specifications when securing hardware during the installation process.




## SAFETY INSTRUCTIONS

Safety glasses should be worn at all times while installing this product.

# ASSEMBLY

## Parts List

Item	Qty	Description
1	1	Trailer hitch
2	4	Hex bolt, M12 x 1.25 - 35mm
3	4	Conical-toothed washer, 1/2"



### Step 1

Temporarily remove the rear underbody panel by removing the ten (10) push fasteners with a flathead screwdriver.

Next, remove the plastic covers from the holes located in the outside of the frame rails.



### Step 2

Carefully lower the exhaust by removing two (2) bolts from the exhaust hanger attached to each of the frame rails.

**Note:** Place jack stands or other suitable supports under the exhaust while working to prevent damage to the vehicle.



### Step 3

Raise the hitch into position and loosely secure the hitch with the four (4) supplied M12 bolts and four (4) 1/2" washers.

Refer to the conical tooth washer diagram on page 2.



### Step 4

Torque all M12 hardware to 86 ft-lbs.



## Step 5

Use the ribs in the panel as a guide to trim the  
underbody panel to the appropriate measurement.

Reinstall the panel and exhaust hangers  
that were initially removed in steps 1 and 2.



## TOWING BASICS & SAFETY INFORMATION

For information on safely towing your trailer, visit [curtmfg.com/understanding-towing](https://curtmfg.com/understanding-towing).